water \alpha aze

Attaches to Most Brands of Pressure Washer

Suctioning Capacity of up to 40 GPM

Optional Sludge Cart for Collecting Sludge

Optional Sludge Bag for Ease in Disposal

Stop Spraying and Start Suctioning

Convert your pressure washer into a high volume transfer pump simply by attaching Water Maze's Pit Cleaner.

Once attached to the pressure washer, the Pit Cleaner begins suctioning wastewater, mud, grass, and other sludge from your pit, basement, pond, or wherever you need liquid removed.

Flow capacity is approximate and depends on the flow rate (GPM) and pressure (PSI) of your pressure washer. The chart below indicates how the flow and

PIT CLEANER SUCTION CAPACITY		
PW* Flow Rate	PW* Pressure	Suction Capacity
2.0 GPM	1000 PSI	15 GPM
3.5 GPM	1500 PSI	25 GPM
4.2 GPM	2000 PSI	30 GPM
5.2 GPM	3000 PSI	40 GPM
* PW = Pressi	ure Washer	

pressure work together to deliver the Pit Cleaner's suctioning capacity.

The Sludge Cart is used in conjunction with the Pit Cleaner to help you easily dispose of mud, grass and sludge.

The cart catches the dirty, mucky water suctioned from your pit into a porous collection bag. Water can be strained through the bag and back into a collection pit, leaving only sludge in the bag.

After drying, the bag can be disposed of properly, according to local environmental standards.

Distributed by:

PIT CLEANER

Attaches to a Pressure Washer and Suctions Sludge from a Pit



Pit Cleaner Specifications

Part No.	Description
30-575	Pit Cleaner for suctioning mud from a collection pit (includes wand, suction attachment and hose)
30-580	Sludge Cart (comes with 5 sludge bags)
9-5017	Sludge Bag, Cotton Fiber, Biodegradable, Package of 1



8.914-142.0 Rev 7/07 Tel 800-347-6116 Fax 800-535-9164 info@wmaze.com Specifications and product descriptions subject to change without notice. © 2007